


ELECTRICAL GAUGES W/WARNING

52mm JDM SERIES WHITE / AMBER LED DISPLAY

Air fuel / ratio



Setting warning / Mute Feature

To set the warning feature:

After the opening ceremony is complete, Press and hold the Button down for approx 5 seconds until the pointer begins to blink. Release button. Push and hold button to move quickly across the scale or Toggle button to move pointer in small increment. Once you have the pointer were you want it, wait 5 second to “set” and pointer will stop blinking.

Warning sound mute feature:

- 1.) With ignition key in off position, press and hold button- Turn ignition on, wait for pointer to come to a rest then release button.
- 2.) To turn sound back on-Repeat step 1

Backlight color select feature:

- 1.) There are two different color LED backlight display in one gauge: White and Amber.
- 2.) Press button to select a backlight color in sequence.