


ELECTRICAL GAUGES W/PEAK

TRANSPARENT LENS SERIES AMBER RED & SUPER WHITE LED

(270° SCALE)

Boost / Vacuum Gauge

OPENING CEREMONY

1


POWER WIRE  
(EITHER SIDE IS OK)

WARNING CONNECTOR

SENSOR WIRE.

RED - BATTERY(+)  
BLACK - BATTERY(-)  
WHITE - NOTE  
ORANGE - NOTE

BACK VIEW

2

DOUBLE-SIDED TYPE

VISOR

METER


CORD

0.1-0.2in

BUFFER

METER CUP & HOLDER


SET KEY

3

DOUBLE-SIDED TYPE

CORD

WARNING LIGHT HAVE TO BUY EXTRALY.

4

1.MUTE SELECTER  
SET KEY HOLD AFTER POWER ON.

2.PEAK SELECTER

NORMAL MODE -> SET KEY -> PEAK MODE -> SET KEY -> NORMAL MODE

HOLD SET KEY 3SEC -> CLEAR PEAK -> NORMAL MODE


"PEAK LED FLASH"

3.WARNING SET SECECTER

HOLD SET KEY 5 SEC -> SET KEY -> WARNING SET MODE -> SET KEY -> POINTER MOVE SLOWLY

"POINTER LED FLASH"

HOLD SET KEY -> POINTER MOVE QUICKLY -> OVER 5SEC -> NORMAL MODE

5

Boost / Vacuum Sensor

Surge Tank

Pressure Regulator


T-Fitting

Air Filter

Hose

Red White Black

BOOST INSTALLATION

6


WHITE CONNECTOR

SENSOR WIRE

BLACK RED WHITE

VACUUM / BOOST SENSOR

BACK VIEW

7

NOTE: GAUGE REQUIRE FUNCTION

REQUIRE FUNCTION		INSTALLATION
DAY TIME	NIGHT TIME	
WHITE SCALE	WHITE SCALE	WHITE WIRE->connect to ACC. AMBER WIRE->NO connect
AMBER SCALE	AMBER SCALE	WHITE WIRE->NO connect AMBER WIRE->connect to ACC.
WHITE SCALE	AMBER SCALE	WHITE WIRE-> connect to ACC AMBER WIRE->connect to PARKING LAMP.
AMBER SCALE	WHITE SCALE	WHITE WIRE->connect to PARKING LAMP AMBER WIRE->connecto to ACC.

8