



# Performance Boost Gauge

Green/White Display (270° Scale)

## Electrical




Cut boost line and install supplied plastic "T" fitting. Connect "T" fitting to In-Line Filter with supplied hose. Then connect In-Line Filter to sender with supplied hose.



## Wiring Instructions


**Red-** 12v Accessory Power  
(also run to sender)  
**Black-** Ground  
**White-** 12v Accessory power  
**Orange-** Headlight switch  
**green-** boost sender  
(Connects to white wire from sender)

\*Note. Please be sure not to over tighten the screw..



Installing U bracket.

## Mechanical



The instructions below will make the gauges white during the day and Green at night. For any other configurations please refer to the lighting diagram below.

## Wiring Instructions

**Red-** 12V Accessory power  
**Black -** Ground  
**White-** Accessory power on  
**Green-** Headlight switch  
(Once you turn the headlights on the gauge turns Green)

## Lighting Diagram

Day Time	Night Time	
White	White	White — Connect to acc. Power Green — Do not connect
Green	Green	White — Do not connect Green — Connect to acc. Power
White	Green	White — Connect to acc. Power Green — Connect to parking lamp
Green	White	Green — Connect to acc. Power White — Connect to parking lamp

\*Most Common